



**KING  
KOOKER**



OUTDOOR COOKERS

ASSEMBLY INSTRUCTIONS  
AND USE AND CARE  
MANUAL FOR MODEL# 2106  
PROPANE SMOKER

MODEL/SERIAL # \_\_\_\_\_

THE INSTRUCTION MANUAL CONTAINS IMPORTANT INFORMATION  
NECESSARY FOR THE PROPER ASSEMBLY AND SAFE USE OF THE APPLIANCE.  
READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS BEFORE  
ASSEMBLING AND USING THE APPLIANCE. FOLLOW ALL WARNINGS AND  
INSTRUCTIONS WHEN USING THE APPLIANCE.  
KEEP THIS MANUAL FOR FUTURE REFERENCE.

**METAL FUSION, INC.**

712 St. George Avenue.

Jefferson, LA 70121

**If you have any problems or questions,**

**CALL US FIRST TOLL FREE AT**

**1-800-783-3885**

7:30 AM to 3:30 P.M. CST • Monday through Friday

**(504) 736-0201**

[www.kingkooker.com](http://www.kingkooker.com)

**⚠ WARNING**

FAILURE TO FOLLOW THESE INSTRUCTIONS  
AND WARNINGS COULD RESULT IN FIRE, EXPLOSION, BURN HAZARD OR  
CARBON MONOXIDE POISONING WHICH COULD CAUSE PROPERTY  
DAMAGE, PERSONAL INJURY OR DEATH.

## **DANGER**

**If you smell gas:**

- 1. Shut off gas to the appliance.**
- 2. Extinguish any open flame.**
- 3. Open front door slowly. Open the door approximately 1-2 inches (2.5-5.0cm) and check for flare-up before opening door completely. Quick introduction of oxygen to the cooking chamber could lead to possible flare-up.**
- 4. If odor continues, keep away from the appliance and immediately call your Fire Department.**

**FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN FIRE OR EXPLOSION WHICH COULD CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**

## **DANGER**

- 1. Never operate this appliance unattended.**
- 2. Never operate this appliance within 10 feet (3.05m) of any structure, combustible material or other gas cylinder. Do not locate this appliance under ANY overhead construction.**
- 3. Only use propane burning units outdoors. Risks include fire and carbon monoxide fumes. Lack of ventilation can cause injury or death.**
- 4. Never operate this appliance within 25 feet (7.5m) of any flammable liquids or vapors.**
- 5. Heated liquids and equipment remain at scalding temperatures long after the cooking process. Never touch cooking appliance until it has cooled to 100°F (38°C) or less.**
- 6. If a fire should occur, keep away from the appliance and immediately call your Fire Department. Do not attempt to extinguish an oil/grease fire with water. When cooking, have a Type BC or ABC fire extinguisher readily available. A Type BC or ABC fire extinguisher may, in some circumstances, contain the fire.**

**FAILURE TO FOLLOW THESE INSTRUCTIONS AND WARNINGS COULD RESULT IN FIRE, EXPLOSION, BURN HAZARD OR CARBON MONOXIDE POISONING WHICH COULD CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**

# **WARNING**

## READ AND UNDERSTAND BEFORE USING THIS PRODUCT

(Throughout this manual the words appliance, cooker and smoker will be used interchangeably to refer to the King Kooker<sup>®</sup> Outdoor Cooker.)

- 1) This is an **ATTENDED** appliance. Do **NOT** leave this appliance unattended while in use. Monitor the appliance when hot after use [cooking chamber above 100° F (38°C)]. Heated liquid and equipment can remain at scalding temperatures long after cooking has ended.
- 2) Keep children, pets and any unauthorized persons away from the appliance at all times.
- 3) The use of alcohol, prescription or non-prescription drugs may impair your ability to properly assemble or safely operate this appliance. Do **NOT** assemble or operate this appliance if using alcohol, prescription or non-prescription drugs.
- 4) This appliance is for **OUTDOOR** use only. Do **NOT** use in a building, garage, tent or any other enclosed area. Do **NOT** use in or on a recreational vehicle or boat. **NEVER** use this appliance as a heater.
- 5) Do not locate this appliance under **ANY** overhead construction. Keep a minimum clearance of 10 ft.(3.05m) from the sides, front and back of the appliance to **ANY** construction. Keep the area clear of any combustible material. Do not use on or under any apartment or condo balcony or deck.
- 6) When cooking, the appliance must be on a level, stable, noncombustible surface such as brick, concrete or dirt. Not suitable are surfaces such as wood, asphalt or plastic which may burn, blister or melt.
- 7) Keep the fuel supply hose away from any heated surfaces. Only the LP hose/regulator assembly specified by Metal Fusion, Inc. should be used with the appliance.
- 8) When cooking, have a Type BC or ABC fire extinguisher readily available. In the event of an oil/grease fire, do not attempt to extinguish with water. Immediately call the Fire Department. A Type BC or ABC fire extinguisher may, in some circumstances, contain the fire.
- 9) In the event of rain, snow, hail, sleet or other forms of precipitation while cooking, turn off the appliance burners and gas supply. Do not attempt to move the appliance.
- 10) This appliance, including doors, racks and pans, gets dangerously hot in use. Use well insulated pot holders or oven mitts for protection from hot surfaces when handling.
- 11) Do **NOT** move the appliance when in use. Allow the smoker to cool to 100°F (38°C) before moving or storing.
- 12) Avoid bumping of or impact with the appliance to prevent contact with hot appliance, spillage or splashing of hot cooking liquid.
- 13) See Use and Care section for LP Gas Cylinder Information. A 20 pound cylinder should be used with this cooker. The LP-gas supply cylinder used must have a protective collar and must be constructed and marked in accordance with the specifications for LP-gas cylinders of the U. S. Department of Transportation (DOT) or the National Standard of Canada, CAN/CSA-B339, Cylinders, Spheres and Tubes for the Transportation of Dangerous Goods. Do not store a spare LP-gas cylinder under or near this appliance. Never fill the cylinder beyond 80% full. For proper vapor withdrawal, the 20 lb. cylinder should be used in the proper upright position. Cylinder must be turned off while not in use. Failure to follow these instructions and warnings could result in fire or explosion which could cause property damage, personal injury or death.
- 14) This appliance is not intended for commercial use.
- 15) Use King Kooker<sup>®</sup> appliances only in accordance with state and local ordinances, or in the absence of local codes, with the National Fuel Gas Code, ANSI Z223.1/NFPA 54, Storage and Handling of Liquefied Petroleum Gases, ANSI/NFPA 58 or CSA B149.1, Natural Gas and Propane Installation Code.

**FAILURE TO FOLLOW THESE INSTRUCTIONS AND WARNINGS COULD RESULT IN FIRE, EXPLOSION, BURN HAZARD OR CARBON MONOXIDE POISONING WHICH COULD CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**

# METAL FUSION, INC.

## LIMITED ONE-YEAR WARRANTY

### WHAT THIS WARRANTY COVERS

This warranty covers all components of this outdoor cooker to be free from defects in materials and workmanship, with the exceptions stated below.

### HOW LONG COVERAGE LASTS

This warranty runs for one year from the date of purchase. Please keep your receipt with this manual for future reference.

### WHAT IS NOT COVERED

This warranty does not cover the following:

*Incidental and Consequential Damages.* This warranty does *not* cover incidental and consequential damages arising in any way out of the use of this outdoor cooker. The liability of Metal Fusion, Inc. is, in any event, limited to the amount of the original purchase price of this outdoor cooker, and remains in force only as long as the product remains in its original, as-built configuration. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

*Neglectful Operation.* This warranty does *not* cover any loss or damage arising in any way due to the negligent operation of this outdoor cooker.

*Altered, Repaired or Misused Equipment.* This warranty does *not* cover any loss or damage arising in any way out of the use of this outdoor cooker when it has been altered, repaired by persons other than Metal Fusion, Inc., or when it has been abused or misused, or when it has been used other than in accordance with the manufacturer's operating instructions, including, without limitation, any damage to the consumer's pots because they were placed on a lit cooker while the pot is empty. When using smoker, use only the porcelain water pan provided.

*Other Assumed Responsibilities.* Unless otherwise provided by law, this warranty does *not* cover any responsibility or liability arising in any way out of the use of this product where that responsibility or liability was purportedly assumed by any other person or agent.

*Paint, Discoloration and Rust.* This warranty does *not* cover the paint on the outdoor cooker, as in a normal use of the outdoor cooker, the paint will be burned off. Nor does this warranty cover discoloration or rust as these occurrences are part of the cooker's normal wear and tear.

### WHAT METAL FUSION, INC. WILL DO

Metal Fusion, Inc. will repair or replace any outdoor cooker that proves to be defective in materials or workmanship. In the event repair is not possible or economically feasible, Metal Fusion, Inc. will replace your outdoor cooker with an identical or substantially equivalent outdoor cooker. Metal Fusion, Inc. will perform this service at no charge to you, except for the actual cost of shipping and handling the outdoor cooker or replacement parts.

### HOW TO GET SERVICE

In the event you have a problem or malfunction with your outdoor cooker, simply call Metal Fusion, Inc. at (800) 783-3885.

### HOW STATE LAW APPLIES

This warranty gives you specific rights, and you may have other rights which vary from state to state.

OWNER'S REGISTRATION



Dear Customer,

Thank you for purchasing a King Kooker®! Please take a moment to fill out your registration form and return it to us. We are always happy to hear suggestions and comments from our customers about our products. Completion of this registration allows us to contact you if the need arises. Please keep your receipt with your instruction manual. It will be necessary as a proof of purchase for us to help you if there is a problem with your cooker.

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Phone: \_\_\_\_\_

Email: \_\_\_\_\_

Model# \_\_\_\_\_

Date of Purchase \_\_\_\_\_

Place of Purchase \_\_\_\_\_

Price Paid \_\_\_\_\_

Was this a gift \_\_\_\_\_ or did you \_\_\_\_\_ purchase it yourself?

\_\_\_\_\_  
\_\_\_\_\_

Comments: \_\_\_\_\_

\_\_\_\_\_  
\_\_\_\_\_

A SATISFIED CUSTOMER IS OUR MAIN GOAL. If you have any questions or problems, please call us at 1-800-783-3885 before returning the product to the point of purchase. Please have your receipt available when calling.

*THANK YOU,  
ENJOY YOUR COOKING EXPERIENCE.*



TAPE HERE

FOLD

---

---

---

---

Place  
Stamp  
Here

**METAL FUSION, INC.**

712 St. George Avenue  
Jefferson, LA 70121

FOLD

---

READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE  
USING YOUR KING KOOKER® PRODUCT

TABLE OF CONTENTS

Warnings.....2-3

Warranty.....4

Owners Registration.....5-6

Table of Contents .....7

Section I - King Kooker® Outdoor Cooker Assembly .....8-11

Section II - Use and Care.....12-18

    LP Gas Cylinder Information.....12

    Connection Instructions.....12

    Leak Test Instructions.....12

    Placement Instructions.....13

    Preparation of Smoker Cabinet.....13-14

    Lighting Instructions.....15

    Smoking with Propane.....16

    King Kooker® Smoking Chart.....16

    Turning Off and Storing the Cooker after Use.....17

    Maintenance Of Outdoor Cookers And Accessories.....17-18

    Injecting Techniques for Turkey, Chicken and Roast.....18

Section III - Recipes.....19-23

    Smoking.....19

    Using Wood Chips to Add Flavor.....19

    Using Marinades/Dry Seasonings to Add Flavor.....19

    Recipes for Smoked Foods.....19-23

    Smoked Turkey or Chicken.....19

    Jalapeno Corn Bread Dressing.....20

    Andouille Dressing.....20

    Oyster Dressing.....20

    Stuffing Directions.....20

    Smoked Split Whole Chicken.....21

    Smoked Chicken Using Marinade Rack.....21

    Smoked Ribs.....21

    Smoked Brisket.....22

    Smoked Leg of Lamb.....22

    Smoked Venison Roast.....22

    Smoked Salmon Steaks.....23

    Smoked Butterflied Shrimp.....23

    Smoked Baked Potatoes.....23

    Smoked Corn on the Cob.....23

Section IV - Frequently Asked Questions.....24

# SECTION I

## OUTDOOR COOKER ASSEMBLY

### **▲WARNING**

THE USE AND CARE MANUAL MUST BE READ AND UNDERSTOOD BEFORE USING THE APPLIANCE

(Throughout this manual the words appliance, cooker and smoker will be used interchangeably to refer to the King Kooker® Outdoor Cooker.)

## 2106 ASSEMBLY INSTRUCTIONS

### **Tools Required:**

Phillips Head Screwdriver, Adjustable Wrench, Leak Testing Solution

1. Before assembling, check that all smoker components are included in the shipping carton. Identify these smoker parts from the parts list below. If any parts are missing, contact Metal Fusion, Inc. at (800)783-3885 between the hours of 7:30am and 3:30pm CST Monday through Friday for replacements.



**Figure 1**


### **PARTS LIST:**

- (1) Smoker Cabinet
- (4) Appliance Legs
- (2) Cool Grip Side Handles
- (2) Cool Grip Door Handles
- (1) Side Door Latch (Small Bend) and Nut
- (1) Front Door Latch (Big Bend) and Nut
- (2) Side Dampers
- (1) Adjustable Stack with Damper and Red "HOT" Signal Plate
- (1) Face Panel Assembly
  - Installed Components Include:
    - (1) Control Knob
    - (1) Brass Valve with Attached Hose/Regulator
    - (1) Red Ignitor Button
- (1) Thermometer
- (1) Burner Shroud with Steel Burner and Attached Piezo Line
- (1) Wood Chip Pan with Lid (Cast Iron)
- (1) Water Pan (Porcelain)
- (1) Sliding Marinade Rack
- (3) Sliding Racks
- (3) Sausage Hanging Racks
- (29) Black Bolts




2. Read assembly instructions, and understand sequence of assembly, before commencing to assemble your smoker.
3. Turn the smoker cabinet upside down. Install the four appliance legs using three black bolts on each leg to the bottom of the smoker cabinet. The two front legs will have holes for connection to the face panel assembly. After all four legs are connected, install the face panel assembly onto the front appliance legs using four black bolts. Reference Figure 2 for proper leg and face panel assembly placement.
4. Locate the hose and regulator. Check that the 3/8" female flare swivel end of the hose is tightened onto the brass adapter on the bottom of the valve. The hose to valve connection must be tightened and leak tested (see Leak Test instructions on page 12). See below Figure 2.

**Figure 2 - Hose Connection Diagram**




5. Install the burner shroud with steel burner onto the bottom of the smoker using three black bolts as pictured in Figure 3. Make sure the end of the venturi tube of the burner is placed securely over the end of the valve extending from the backside of the face panel before tightening shroud to base of smoker. Connect the piezo line (line with white plastic covering) to the red ignitor button's black plastic body on the back side of the face panel. Test the connection by pushing the red ignitor button on the face panel. You should see a spark between the end of the exposed piezo wire and burner. If not sparking, check connections and make sure wire is not touching burner. There should be a distance of 3/16" (4.8mm) between the end of the electrode tip and the burner for proper operation.


**Figure 3**



6. Install adjustable stack on top of smoker using four black bolts. The adjustable stack vent should be directed towards the back of the smoker (See Figure 1, page 8).
7. Install cool grip side handles on both sides of smoker using four black bolts (2 on each handle). Bolts should thread towards inside of smoker (See Figure 1, page 8).
8. Install the two side dampers onto smoker cabinet using two black bolts (one bolt on each damper). Bolts should thread toward inside of smoker (See Figure 1, page 8).
9. Install front smoker door handle using one cool grip door handle, front door latch (big bend) and nut. Insert handle through front smoker door as shown in Figure 4. Keep cool grip handle horizontal. Place front door latch (big bend) over threaded end of handle on back side of front smoker door. The bend on latch should be pointed down (See Figure 5 below). Tighten with supplied nut. To latch the door shut, close door and turn handle down to latch in place.




**Figure 4**




**Figure 5**

10. Install side smoker access door handle using one cool grip handle, side door latch (small bend) and nut. Insert handle through side smoker door as shown in Figure 6. Keep cool grip handle horizontal. Place side door latch (small bend) over threaded end of handle on back side of side smoker door. The bend on latch should be pointed down (See Figure 7 below). Tighten with supplied nut. Turn side door handle down and latch in place.




**Figure 6**



**Figure 7**

11. Install cabinet thermometer on front smoker door. Remove brass nut from stem of thermometer and insert stem through the front of the smoker door in hole provided. Reattach nut to thermometer stem on inside of door to tighten. See below Figure 8 for proper thermometer placement.



**Figure 8**

12. Go to the Use and Care Section of this manual for further instructions.

# SECTION II

## USE AND CARE

(Throughout this manual the words appliance, cooker and smoker will be used interchangeably to refer to the King Kooker® Outdoor Cooker.)

---

### LP GAS CYLINDER INFORMATION

King Kooker® Outdoor Cookers are manufactured for use with **20lb. LP Gas Cylinders**. Important information to remember about LP Gas cylinders include:

1. Always read and follow the cylinder manufacturer's instructions.
2. Make sure that the gas cylinder is not overfilled. The maximum weight of a properly filled 20 lb. LP gas cylinder is approximately 38 lbs. Never fill the cylinder beyond 80% full.
3. Make sure that the cylinder valve has the proper connection for a Type 1 appliance fitting.
4. Do not store a spare LP gas cylinder under or near this appliance.
5. Disconnect the cylinder from the cooker for storage.
6. Store the cylinder out of the reach of children.
7. Do not use or store the cylinder in a building, garage or enclosed area.
8. Always use a 20 lb. cylinder in the proper upright position for the proper vapor withdrawal. It should also be stored and transported in the upright position.
9. The cylinder must have a protective collar to protect the cylinder valve.
10. Place dust cap on cylinder valve outlet whenever the cylinder is not in use. Only install the type of dust cap on the cylinder valve outlet that is provided with the cylinder valve. Other types of caps or plugs may result in leakage of propane.
11. Cylinder must be turned OFF while not in use.

#### **▲WARNING**

**ALWAYS READ AND FOLLOW THESE AND THE CYLINDER MANUFACTURER'S INSTRUCTIONS. FAILURE TO FOLLOW THESE INSTRUCTIONS AND WARNINGS COULD RESULT IN FIRE, EXPLOSION, BURN HAZARD OR CARBON MONOXIDE POISONING WHICH COULD CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**

---

### CONNECTION INSTRUCTIONS

1. Check that the control knob on your smoker is set to not allow gas flow (in the off position).
2. Attach the regulator to the cylinder valve by turning the Type 1 fitting clockwise. Hand tighten with the regulator positioned upright. Refer to the hose connection diagram for the appliance, page 9 (**FIGURE 2**).
3. Perform the Leak Test:

#### LEAK TEST


Before lighting the appliance, a thorough leak test must be satisfactorily completed using a non-ammonia soapy water solution (50% non-ammonia soap and 50% water). This is to be applied with a small brush to all gas joints after the cylinder valve is opened (no more than 1/2 turn). If bubbles are seen, indicating a leak, turn off the cylinder and tighten the leaking connection until a further leak test shows no leaks.

If tightening the connection does not stop the leak, call Metal Fusion, Inc. (800) 783-3885, for assistance.

**NEVER USE HOSE/REGULATOR ASSEMBLY IF LEAKING.**

4. Before lighting the cooker, check that the venturi tube is free of obstruction and that the burner's venturi tube is properly positioned around the orifice at the end of the brass valve as pictured in **FIGURE 3** on page 10. Both situations must be corrected if necessary before lighting to prevent flashback.

# PLACEMENT INSTRUCTIONS



## ⚠ WARNING


Keep twenty-four inches (.61m) between the cylinder and the appliance. Placing the cylinder too close to the appliance could result in fire or explosion which could cause property damage, personal injury or death.

The hose connecting the appliance to the tank poses a trip hazard. Do not step over the hose or walk between the cylinder and appliance. Tripping could cause the appliance or cylinder to tip over, leading to fire or explosion which could cause property damage, personal injury or death.

1. Never operate this appliance within 10 feet (3.05m) of any structure, combustible material or other gas cylinder. Never operate this appliance within 25 feet (7.5m) of any flammable liquids or vapors.
2. There must be no combustibles or roof overhead.
3. Keep 24 inches (.61m) of space between the LP gas cylinder and the appliance.
4. The LP gas cylinder and appliance must be located so that any wind is blowing the heat of the appliance away from the propane cylinder. This also helps fire prevention by blowing the flames of a grease fire away from the propane cylinder.

## PREPARATION OF SMOKER CABINET

1. Next, prepare the wood chip and water pans for smoking (See below picture for proper pan placement). The water pan should always be installed into the smoker when cooking. The water pan will collect drippings from hot food and extend your burner's life. Only use the water pan provided with this unit.



Top lip of water pan slides in and rests on rack.

Wood chip pan sits on bottom rack.

**INSERT AND REMOVE PANS THROUGH SIDE ACCESS DOOR**

**Wood Chip Pan for Wet or Dry Smoking:** If a wood smoked flavor is desired, use the wood chip pan, placed on the bottom brackets of the smoker body. Do not place the wood chip pan in the smoker cabinet at the beginning of the smoking process. When only one hour of smoking time is left remove the lid from the wood chip pan and add the desired amount of wood chips. Place lid back on the wood chip pan. Open the side door of the smoker. Wearing protective mitts, carefully place the wood chip pan onto the bottom rack of the smoker cabinet. The smoker will be extremely hot. Close the door and allow the remaining cooking time to pass. Refer to "Using Wood Chips to Add Flavor" on page 19 for more information.

**Water Pan for Wet Smoking:** Fill the water pan to within 1/2 inch (1.27 cm) of the top with water and your favorite marinade, soft drink or beer. Place the water pan inside the smoker using the receiving brackets right above the wood chip pan, before lighting your cooker. Check the water pan every hour during cooking using protective oven mitts. The smoker and water pan will be extremely hot. Use caution when removing and installing the water pan as hot liquid can splash. Never allow the water to completely evaporate.


**For Dry Smoking:** Do not add water or marinade to the water pan.

**Tip:** Line the water pan with aluminum foil for easy clean up.

## 2. Preparing the Racks:

Open door to main smoking chamber. Arrange food in smoking chamber as desired using supplied racks. This smoker is equipped with several racks to allow for smoking a wide variety of foods at once. The eight pre-installed mounting slides allow for varying rack placement inside the smoker cabinet. Arrange racks and food before lighting. Use well insulated pot holders or oven mitts for protection from hot surfaces when handling. Use caution and exercise care when operating the racks. Support the rack completely with your hands when you slide it forward to check the food or to remove the rack. Do not extend the rack more than halfway out of the smoker unless supporting it with both hands to prevent spilling the food as the rack is removed from the smoker. Do not release the rack unless it is fully inserted into the smoker or completely removed from the smoker and placed on a stable safe surface to check food.


**Sliding Racks (3):** Locate three racks without marinade indentions (flat). The racks are equipped with guide tabs (two on each rack). The guide tabs are designed to help keep the racks centered while installing or removing from the cabinet. Insert the side of the rack with the two guide tabs into the mounting slides first. Slide rack completely to rear of the smoker cabinet. To remove the rack, slightly raise front of rack and carefully pull to front.



**Sliding Marinade Rack (1):** The marinade rack is designed with three indentions for placement of marinade vessels. Soft drink or beer cans are the perfect diameter to be used for this purpose. The cans, filled with marinade of choice, should be placed in the indentions on the rack. Place the large opening of the cavity of the chicken onto the can so that the chicken rests on the rack. The rack can then be placed into the mounting slides inside the smoker cabinet at the desired height for cooking. Please see sliding rack installation instructions above.



**Sausage Hanging Racks (3):** The three separate sausage hanging racks are designed to hook over the pre-installed mounting slides. Sausage can then be hooked/draped over the hooks for smoking.







3. Light the smoker according to the “Lighting Instructions” on page 15.

# LIGHTING INSTRUCTIONS

## **⚠WARNING**

**THE SMOKER MUST NOT BE LIT UNTIL THE PRECEDING PLACEMENT INSTRUCTIONS HAVE BEEN COMPLETELY FOLLOWED.**

1. Check the casting (steel burner) to make sure it is set up as per **Figure 3 on page 10**. Open the main smoker door. **Never light the burner with the smoker door closed. Never lean into the smoker chamber while lighting.** Locate the red plate embossed with HOT on the stack on top of the cabinet. Turn the plate until it is fully exposed. This signals that the smoker is HOT while in use.
2. Make certain that the control knob on the smoker is turned to the OFF position.
3. Open cylinder control valve by turning it counterclockwise as per the diagram (**Figure 1**).
4. There are multiple ways of lighting your smoker. Choose one of the following methods:
  - A. Piezo Ignition** - Push and turn the control knob towards the **"HIGH"** position. Immediately press the red ignitor button next to the control knob repeatedly until ignition occurs (see **Figure 2**). When lighting the smoker, if ignition does not occur in 3 to 5 seconds, turn the control knob and cylinder valve off. Wait 5 minutes for gas to disperse. Repeat procedure.
  - B. Multi-Purpose Lighter/Paperbook Match** - Push and turn the control knob towards the **"HIGH"** position. Immediately place a lit multi-purpose lighter or paperbook match through the hole on the side of the burner shroud as shown in **Figure 3**. When lighting the smoker, if ignition does not occur in 3 to 5 seconds, turn the control knob and cylinder valve off. Wait 5 minutes for gas to disperse. Repeat procedure.
5. Check that the flame is blue and that the flames are emitted completely around the burner (see **Figure 4**). If there is a yellow flame, or if some ports have no flame, this indicates there may be an obstruction in the venturi tube or ports. Check the maintenance instructions on page 17 for more information regarding a yellow flame or blockage.
6. Always monitor the flame throughout the cooking process. If at any point in the cooking process the flame is accidentally extinguished, immediately turn the control knob and cylinder valve OFF. Open main smoker door slowly, wait 5 minutes for gas to disperse and relight the smoker according to the lighting instructions (#1-#5) in this section.



# SMOKING WITH PROPANE

1. Once the cooker is lit according to the "Lighting Instructions" on page 15, set the flame intensity to the desired setting. When smoking with propane, the heat intensity will remain constant.
2. Use the thermometer to monitor the temperature of the smoker. If it falls lower than the desired temperature, turn up the flame intensity by adjusting the control knob on the face plate. Adjust the damper(s) more open to increase heat or closed to reduce heat.
3. When checking food for doneness, open the door approximately 1-2 inches (2.5-5.0cm) and check for flare-up before opening door completely. Quick introduction of oxygen to the cooking chamber could lead to possible flare-up. Opening the door adds cooking time to the food. When the outside temperature drops below 60° F (16° C), we suggest adding more cooking time.
4. Use caution and exercise care when operating the racks. Support the rack completely with your hands when you slide it forward to check the food or to remove the rack. Do not extend the rack more than halfway out of the smoker unless supporting it with both hands to prevent spilling the food as the rack is removed from the smoker. Do not release the rack unless it is fully inserted into the smoker or completely removed from the smoker and placed on a stable safe surface to check food.
5. See below chart for estimated cooking times. Variations will result depending upon the distance of the food to the flame, amount of food in the smoker and the number of times the door is opened during cooking.

## KING KOOKER SMOKING CHART

FOOD	QUANTITY	APPROX. COOKING TIME 300-350°F(149-177°C)-MEDIUM HEAT	FULLY COOKED MEAT/TEMP/DESC. (Use a meat thermometer)
<b>Fish &amp; Seafood</b>			
Whole, Large	4 to 6 lbs.	2 to 3 hrs.	Flakes Easily With Fork
Whole, Small	FULL RACK	1 to 2 hrs.	Flakes Easily With Fork
Fillet	FULL RACK	3/4 to 1 hr.	Flakes Easily With Fork
Shrimp, Crablegs	FULL RACK	1/2 to 1 1/2 hrs.	Pink, Resilient
Lobsters			Meat Pulls Away from Shell
<b>Poultry</b>			
Chicken, Whole or Split	1 to 4 Fryers	2 1/2 to 3 hrs.	{ Slice Leg Joint to Check for Doneness 190 °F(87° C) 190 °F(87° C) 190 °F(87° C) 190 °F(87° C) 190 °F(87° C) 190 °F(87° C) Well Done
Chicken, Stuffed	1 to 4 Fryers	3 1/2 to 4 1/2 hrs.	
Chicken, Breast Parts	FULL RACK	2 1/2 to 3 hrs.	
Turkey	12 to 20 lbs.	4 to 5 hrs.	
Turkey Stuffed	12 to 20 lbs.	4 to 5 hrs.	
Small Game Bird	FULL RACK	1 1/2 to 2 1/2 hrs.	
Large Game Bird (Duck, Pheasant, Goose)	5 to 7 lbs.	3 to 4 hrs.	
<b>Beef</b>			{ 140 °F(60° C) Rare 160 °F(71° C) Medium 170 °F(77° C) Well Done
Whole Rump Roast	4 to 6 lbs.	3 to 5 hrs.	
Brisket	1 to 6 lbs.	5 to 7 hrs.	
Ribs	FULL RACK	3 to 3 1/2 hrs.	
<b>Pork</b>			
Ribs	FULL RACK	3 to 3 1/2 hrs.	170 °F(77° C)
Chops (3/4")	FULL RACK	2 1/2 to 3 1/2 hrs.	170 °F(77° C)
Ham (Pre-Cooked)	All Sizes	2 to 3 hrs.	130 °F(54° C) Well Done Meat Pulls Away From The Bone
<b>Lamb</b>			
Leg	3 to 6 lbs.	3 to 5 hrs.	180 °F(82° C)
<b>Wild Game</b>			
Venison	1 to 5 lbs.	2 to 5 hrs.	170 °F (77° C)

### ALL COOKING TIMES ARE ESTIMATES

A meat thermometer can determine the proper amount of doneness.

Place the thermometer into the thickest part of the meat for 5 minutes to register the temperature immediately after removing from smoker. Make sure it is not touching the bone.



# TURNING OFF AND STORING THE SMOKER AFTER USE

## **▲WARNING**

**NEVER MOVE THE SMOKER WHILE IN USE OR STILL HOT{ABOVE 100°F (38°C)}.**

1. After each use turn OFF the King Kooker® at the control knob first, then at the gas cylinder valve. **Check to make sure there is no flame and all valves are OFF.** Do not leave the cooker until it has cooled completely. When removing food from the smoker wear protective mitts.
2. Disconnect the regulator from the cylinder by turning the Type 1 fitting counterclockwise until the regulator is separated from the tank.
3. Storage of this cooker indoors is permissible only if the cylinder is disconnected and removed from the cooker. Do not use or store cylinder in a building, garage or enclosed area. Read and follow cylinder manufacturer's instructions. The cylinder must be stored out of the reach of children at all times. Keep entire unit in area to avoid insects and contamination that can clog the venturi tube.

## **▲WARNING**

**FAILURE TO FOLLOW THESE INSTRUCTIONS AND WARNINGS COULD RESULT IN FIRE, EXPLOSION, BURN HAZARD OR CARBON MONOXIDE POISONING WHICH COULD CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**

---

## MAINTENANCE OF OUTDOOR COOKERS AND ACCESSORIES

1. The area where the cooker will be used must be kept clear and free from combustible materials, gasoline and other flammable vapors and liquids. Before each use of the cooker, inspect and remove any combustible items.
2. The flow of combustion and ventilation of air must not be obstructed. The cooker must be set in an open area with 10ft. (3.05m) of space on all sides and no roof or overhang overhead. Check the location and placement of the cooker before each use.
3. Before each use of the appliance check the burner/venturi tube for insects, insect nests, and other obstructions. A clogged tube can lead to a fire beneath the appliance.
4. Follow all Lighting Instructions in the Use and Care Manual each time the cooker is used. Check the flame for proper color and appearance. The flame should burn with a primarily blue color. If a strong yellow flame is present, this could indicate an obstruction in the burner/venturi tube.  
If there is any obstruction or a yellow flame, turn off the cooker and allow time for it to cool. Disconnect the piezo by pulling the line away from the black plastic housing. Remove burner from flatbar of burner shroud. Check the venturi tube of burner with a flashlight to see if there is a blockage. If a blockage is present, use a wire such as a coat hanger to slide into the venturi tube to remove the blockage. Re-assemble and light the cooker again as per the instruction manual. If this does not resolve the problem, please call Metal Fusion, Inc. at (800) 783-3885 between the hours of 7:30am-3:30pm (CST) Monday through Friday.
5. Always use the LP Hose/Regulator assembly supplied with the appliance. Before each use of the appliance check the LP Hose for evidence of abrasion, wear, cuts or leaks. If there is any damage to the hose, the hose/regulator assembly must be replaced prior to using the appliance. Contact Metal Fusion, Inc. at (800) 783-3885 for information regarding a replacement hose assembly. Only the LP Hose/Regulator assembly specified by Metal Fusion, Inc. should be used with the appliance.
6. For purchase of any replacement parts which may have become damaged or lost, please contact Metal Fusion, Inc. at (800) 783-3885 between the hours of 7:30am-3:30pm (CST) Monday through Friday.

- Cleaning of the appliance:  
**Hose/Regulator and Burner/Lighting Components:** If necessary, remove any oil or liquid which has spilled onto the unit during cooking with mild soapy water on a rag and towel dry. Do not immerse the burner unit/components or hose/regulator into water as this will cause rust.  
**Thermometer:** Clean after each use with mild soapy water and towel dry. Do not submerge in liquid or put in dishwasher.  
**Smoker Cabinet/Accessories:** The grill racks and water pan should be washed with a mild soapy water solution after each use. Do not use very abrasive cleaners. They may damage the finish of the product. Wipe out wood chip pan with clean dry rag. The outside of the smoker can be wiped off as needed. Store the appliance in a protected area. Always disconnect the propane cooker from the tank. Follow storage instructions for the tank supplied by the tank manufacturer.
- 

## INJECTING TECHNIQUES FOR TURKEY, CHICKEN AND ROAST

### IMPORTANT:

**BEFORE INJECTING, POUR MARINADE INTO A SEPARATE CONTAINER TO KEEP FROM CONTAMINATING MARINADE.**

## CHICKEN

- Remove giblets and rinse chicken with warm water, drain cavity completely.
- Fill Injector with desired amount of marinade.
- Inject FULL amounts of marinade (approximately 1 oz.) at the breast, thigh and leg. Inject marinade slowly while pulling needle out of meat. This gives even distribution of seasoning. (For best results, insert needle at different angles through the same hole when injecting marinade.)
- Sprinkle outside of chicken generously with King Kooker® Cajun Seasoning, rubbing in well.

## BEEF, PORK & GAME


- Fill Injector with desired amount of marinade.
- Inject marinade 1 to 2 inches apart. Inject marinade slowly while pulling needle out of meat. This gives even distribution of seasoning.
- Pour marinade generously over the roast.

## TURKEY

- Remove giblets, neck, any wires or packaging materials, and pop up timer. Rinse turkey with warm water and drain cavity completely.
- Fill Injector with desired amount of marinade.
- Inject FULL amounts of marinade (approximately 1 oz.) at the breast, thigh and leg. Inject marinade slowly while pulling needle out of meat. (For best results, insert needle at different angles through the same hole when injecting marinade.)
- Sprinkle outside of turkey generously with King Kooker® Cajun Seasoning, rubbing in well.

### CLEANING AND STORAGE

USE SOAP AND WATER TO CLEAN INJECTOR AND ALLOW TO DRY. USE VEGETABLE OIL TO LIGHTLY COAT PLUNGER OF INJECTOR. THIS ALLOWS PLUNGER TO MOVE FREELY IN THE BARREL OF THE INJECTOR.



# SECTION III RECIPES

from  
The King of Outdoor Cooking™

---

READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE USING THE PRODUCT

## SMOKING

Congratulations on your purchase of your King Kooker Outdoor Propane Smoker. You will be delighted with the variety of dishes you can prepare with your smoker. Use your imagination and you can be a gourmet chef, surprising your friends and family with the wonderful meals you will prepare. We have provided a few recipes below to get you started. Reference the "King Kooker Smoking Chart" on page 16 for estimated cooking times and temperatures. We suggest using a King Kooker Meat Thermometer or any other high quality meat thermometer to accurately test for doneness. There are a wide variety of seasonings/marinades available to experiment with and enjoy. Cook with your smoker and EAT LIKE A KING!

**REMEMBER:** When checking or removing food, the smoker, food and racks will be extremely HOT. Always wear protective oven mitts when handling and use caution.

### Using Wood Chips To Add Flavor

Wood chips of various flavors can be added to the wood chip pan when smoking. Some choices are hickory, pecan, apple, cherry, and mesquite. Soak the wood chips for at least one hour to prevent a bitter taste. Wait to add the wood chips until only one hour of smoking time is left. This gives a pleasant flavor to the smoked food without overpowering it with the smoked flavor.

### Using Marinades/Dry Seasonings to Add Flavor

King Kooker marinades and dry seasonings add succulent flavor to all types of cooking. For maximum flavor and taste, generously rub on dry seasonings and inject marinade the night before cooking or at least one hour before. Always cover food and refrigerate once seasoning/marinade is added. Marinade can also be added to the water pan as desired. Garlic Butter and Hot & Spicy King Kooker marinades do an excellent job. King Kooker Cajun and Sweet & Spicy Dry Rub seasonings are great examples of dry seasonings you can use.

## Recipes for Smoked Foods

### Smoked Turkey or Chicken

Ingredients : 12 - 20 lb. Turkey or 4 - 5 lb. whole fryer  
King Kooker Cajun Seasoning  
King Kooker Marinade (Optional)

Prepare your turkey or chicken for cooking by thawing, removing the giblet pack & neck, rinsing the bird inside & out. Pat dry with paper towels. Inject with marinade if desired. Sprinkle King Kooker Cajun Seasoning generously on the bird, inside & out. Check the Smoking Chart on page 16 for approximate times & temperatures. If you prefer to stuff your turkey or chicken, refer to stuffing recipes on the following page.

## Jalapeno Corn Bread Dressing

Ingredients: 2-6 oz. packages of your favorite sweet corn muffin mix & additional ingredients as per the mix instructions.  
1 tbsp. chopped canned jalapeno peppers, drained  
4 oz. canned chicken broth  
4 oz. water  
1/2 cup chopped onions  
1/4 cup chopped bell pepper  
1/4 cup chopped celery  
1 tbsp. chopped parsley  
1/4 cup cooking oil  
4 oz. can sliced mushrooms, drained  
1 well beaten egg

Mix the corn bread batter as per the instructions on the package and add the jalapenos. Oven bake the corn bread and allow to cool. Use a large saucepan and your kitchen stove or an outdoor cooker to prepare the dressing. Place the cooking oil in the pot. Combine the onion, bell pepper, celery, & parsley in the pot. Saute until the onions are clear, not browned. Add mushrooms. Crumble the corn bread and stir into the onion mixture. Add the chicken broth and water. Stir over a low heat for a few minutes. Pour the well beaten egg into the mixture & stir well. This should stuff 1 turkey or 2 chickens. Refer to the stuffing directions on the bottom of this page.

## Andouille Dressing

Ingredients: 18 oz. french bread stuffing mix  
1/4 cup chopped bell pepper  
1/2 cup chopped onion  
1/4 cup chopped celery  
1 tbsp. parsley  
1/2 stick butter  
1 lb. andouille chopped into small pieces  
1 egg well beaten  
1 quart of water

Use a large saucepan and your kitchen stove or outdoor cooker to prepare the dressing. Place the cooking oil in the pan. Combine the onions, bell pepper, celery & parsley in the pot and saute on low flame until the onions are clear, not browned. Add the andouille & saute for a few more minutes. Add the stuffing mix & the water. Continue to simmer while stirring the mixture. Add the egg to the mixture. Stir & remove from the heat. Refer to the stuffing directions on the bottom of this page.

## Oyster Dressing

Ingredients : 1 stick of butter or margarine  
3 large yellow onions finely chopped  
1 bunch of green onions finely chopped  
2 or 3 stalks of celery finely chopped  
2 tbsp. chopped parsley  
5 or 6 dozen oysters, drained  
1 loaf of sliced bread  
Large bowl of water  
2 eggs well beaten  
Salt and Pepper

Use a large saucepan and your kitchen stove or outdoor cooker. Turn on low heat. Place the butter in the pan. Add the yellow & green onions, celery, and parsley to the pan and saute until the onions are clear. Add the oysters to onion mixture. Dip a slice of the bread into the bowl of water and then squeeze the excess water out of the bread. Tear the squeezed bread into pieces & drop into saucepan with onion & oyster mixture. Continue wetting & adding all bread. Stir the mixture occasionally during the process. When the entire loaf of the bread has been added, stir in the eggs. Salt and pepper to taste. Sometimes oysters are very salty. Saute for a few minutes longer & remove from heat. Refer to the stuffing directions on the bottom of this page.

## Stuffing Directions

Stuff into the large cavity of the turkey or chicken and sew closed or close the opening with stuffing pins. Each recipe should adequately stuff 1 turkey or 2 chickens. Refer to the Smoking Chart on page 16 for cooking times. When done, remove the stuffing & carve the turkey or chicken.

## Smoked Split Whole Chicken

Ingredients: 4-5 lb Fryer  
King Kooker Sweet & Spicy Rub

Prepare your chicken for cooking by thawing, removing the giblet pack and neck, and rinsing the chicken inside and out. Pat dry with paper towels. Cut the side opposite the breast straight down the middle into the cavity (do not fully sever chicken). Generously rub in King Kooker Sweet & Spicy Rub seasoning. Place the split chicken on rack with the breast up and the rib cage against the rack. Cook according to the Smoking Chart on page 16. Test for doneness using a meat thermometer.

## Smoked Chicken Using Marinade Rack

The marinade rack included with this smoker can be used to smoke three chickens at one time. Prepare your chicken(s) for cooking by emptying the cavity, rinsing it, and patting dry with paper towels. Generously rub in King Kooker Sweet & Spicy Dry Rub seasoning. Listed below are three suggested marinades for use with this rack:

1. Beer- Open a 12oz. aluminum can of your favorite beer. Insert top of can into the bottom cavity of chicken. Pull chicken over can leaving the bottom of the can exposed. Place can with chicken upright into one of the indentions on the marinade rack.
2. Teriyaki- Pour King Kooker Teriyaki Marinade into a clean empty 12oz. aluminum can. Insert top of can into the bottom cavity of chicken. Pull chicken over can leaving the bottom of the can exposed. Place can with chicken upright into one of the indentions on the marinade rack.
3. Tropical- Mix 1/2 cup of orange juice, 1/2 cup of pineapple juice, and 1/4 cup of lemon juice (10 oz. total). Pour into a clean empty 12oz. aluminum can. Pull chicken over can leaving the bottom of the can exposed. Place can with chicken upright into one of the indentions on the marinade rack.

Using this method of smoking allows the chicken to absorb the flavors of these marinades and retain moisture so the chicken remains "juicy." Use cooking times as per the Smoking Chart on page 16. When planned cooking time has passed, remove the marinade rack with the chicken from the smoker and set the rack on a table. Immediately test for doneness with a meat thermometer. Also you may slice the chicken at the thigh joint to make sure the juices run clear.

## Smoked Ribs

Ingredients: Full Rack of Beef or Pork Ribs  
King Kooker Sweet & Spicy Rub  
King Kooker Barbeque Sauce (Optional)

Rinse ribs to prepare for cooking. Sprinkle Sweet & Spicy Rub generously on the ribs and rub the mixture into the meat. Arrange on the smoker rack and cook according to the Smoking Chart on page 16. For wet ribs, barbeque sauce may be added if desired when one hour of cooking time remains. Also, a second coat of sauce may be added before serving. To test for doneness, slice between the bone, see if it is tender and done to your liking.

## Smoked Brisket

Ingredients: 1-Brisket (1-6 lbs.)  
1-Marinade Injector  
King Kooker Cayenne Garlic Marinade (or any of your favorite King Kooker Marinades)  
Garlic Cloves- as desired  
King Kooker Sweet & Spicy Dry Rub  
Large Pan for Marinating Brisket

Rinse the brisket and pat dry with a paper towel. Inject the brisket as per the instructions on page 18. Make small slits in the brisket and stuff with the garlic cloves. Sprinkle with King Kooker Sweet & Spicy Dry Rub and rub the mixture into the meat. Place the meat into the marinating pan and pour some marinade over the brisket. Cover the brisket in the pan and place in refrigerator to marinate overnight, or at least one hour. When ready to smoke, remove the brisket from the marinating pan and sprinkle again with King Kooker Sweet & Spicy Dry Rub. Place the brisket on the rack and cook according to the Smoking Chart on page 16. When the smoking is complete, remove the brisket from the smoker and immediately check for doneness with a meat thermometer. Slice thinly and enjoy.

## Smoked Leg of Lamb

Ingredients: 3-6 lb. Leg of Lamb  
Garlic Cloves- as desired  
Olive Oil  
Dried Rosemary

Rinse the lamb and pat dry with a paper towel. Slice small slits and stuff each slit with a garlic clove. Rub the lamb with olive oil. Sprinkle generous amounts of rosemary on the lamb. Cover with aluminum foil. Refrigerate and marinate overnight if desired. Remove from marinating pan and place on a rack for smoking. Smoke according to the Smoking Chart on page 16. When the cooking time has passed remove from smoker and immediately check for doneness using a meat thermometer.

## Smoked Venison Roast

Ingredients: Venison Roast  
King Kooker Garlic Butter Marinade or King Kooker Hot & Spicy Marinade  
Sweet & Spicy Dry Rub

Rinse the roast and pat dry with a paper towel. Inject with the King Kooker marinade of your choice according to the marinade injecting tips on page 18. Generously sprinkle and rub the roast with King Kooker Sweet & Spicy Dry Rub seasoning. Place the roast into a pan and cover with foil. Marinate overnight in the refrigerator. Remove from pan and place on the rack of the smoker. Cook according to the Smoking Chart on page 16. When planned cooking time has passed, remove the roast from the smoker and immediately test for doneness with a meat thermometer.

## **Smoked Salmon Steaks**

Ingredients: Salmon Steaks, Approximately 1 1/2" Thick  
King Kooker Cajun Seasoning  
1 - Yellow Onion, Sliced and Separated  
1 - Green Pepper, Sliced into Rings  
1 - Lemon, Sliced

Cover a rack from the smoker with aluminum foil to prevent steak breakage and fish drippings. Arrange the steaks on the covered rack. Prepare your salmon by generously covering with King Kooker Cajun Seasoning on both sides. Place rings of the onion, green pepper, and lemon on top of the salmon steaks. Plan cooking time according to the Smoking Chart on page 16. At the end of the planned cooking time, remove the rack from the smoker and check for doneness. The meat should flake easily with a fork.

## **Smoked Butterflied Shrimp**

Ingredients: Shrimp, 16-20 to the pound  
King Kooker Cajun Seasoning  
1 - Lemon  
1 - Lime

Prepare your shrimp for cooking by thawing, if frozen, and removing the heads. Cut the shrimp down the back and butterfly. Remove the vein, leaving the shells on. Sprinkle generously with King Kooker Cajun Seasoning. Arrange individually on the rack of the smoker. Squeeze lemon and lime over shrimp before placing into the smoker. Cook for the time recommended in the Smoking Chart on page 16. When the planned cooking time has passed, remove the rack from the smoker. Check for doneness by making sure they are a pink color and that shells are separating from the meat.

## **Smoked Baked Potatoes**

Ingredients: Potatoes, Sweet or Russet  
(7 potatoes will fit on the Potato Baking Accessory Rack sold separately for use with this smoker.)  
Cooking Oil

Scrub the potatoes to prepare for cooking. Puncture with the tines of a fork at various points around the potato. Rub each potato with cooking oil. Place upright on the points of a potato rack, or arrange by laying flat on a smoker rack. Cook for approximately 1 1/2 hours at 300°F (149 °C). Remove from the smoker when the cooking time has passed. Check for doneness by sticking with a fork to make sure the potato is soft enough to puncture with minimal pressure. Split and serve with butter and sprinkle with your choice of toppings.

## **Smoked Corn on the Cob**

Ingredients: Corn on the Cob, Frozen or Fresh, with Husk and Silk Removed, and Rinsed  
Butter  
King Kooker Cajun Seasoning

Melt butter in a dish. Brush each ear of corn with a basting brush and sprinkle with King Kooker Cajun Seasoning. Wrap each ear individually with aluminum foil. Arrange on the smoker rack and bake at 300 °F (149 °C) . Plan to cook the fresh corn for 1 1/2 hours and frozen for 1 hour. When cooking time has passed, remove the rack from the smoker and cool the corn before serving.

# SECTION IV

## READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE USING YOUR KING KOOKER® PRODUCT

---

### FREQUENTLY ASKED QUESTIONS AND ANSWERS

**1. What is the problem if the smoker takes too long or will not heat cooking chamber to desired temperature? My cooker's flame appearance is very weak.**

Answer: If the hose assembly has a Type 1 Connection (black/green knob), it is equipped with a flow limiting device. This device is intended to limit the flow of gas should there be a leak between the regulator and the appliance. To achieve a positive gas seal, which will allow for maximum gas flow, the control knob must be set to a completely OFF position before the cylinder valve is opened. A good tip to remember is "TANK IS FIRST ON, LAST OFF."

The Problem Can Be Remedied in Two Ways:

- A.
1. Turn the control knob to the OFF position. Close the tank valve completely by turning it clockwise until it stops.
  2. Check that the Type 1 Connection (black/green knob) is completely tightened to the tank valve.
  3. Wait 5 seconds for the pressure to equalize and for the flow limiting device to reset.
  4. Turn tank valve ON (counterclockwise.)
  5. Turn the control knob to an ON position.
  6. Relight cooker following all lighting instructions contained in this manual. Check for proper flame characteristics.

**OR**

- B.
1. Turn the control knob to the OFF position. Close the tank valve completely by turning it clockwise until it stops.
  2. Remove Type 1 Connection (black/green knob) from the tank valve. The flow limiting device will now reset.
  3. Re-attach Type 1 Connection (black/green knob) to the tank valve. Tighten completely.
  4. Turn tank valve ON (counterclockwise.)
  5. Turn the control knob to an ON position.
  6. Relight cooker following all lighting instructions contained in this manual. Check for proper flame characteristics.

**2. How long will the propane in my tank last?**

Answer: On average, a full tank will give you approximately 15 hours of normal cooking.

**3. I have a new style tank and it won't connect to my regulator. What do I do?**

Answer: The regulator supplied with this appliance has a Type 1 Connection which will attach to the tank valve which has large threads on the valve outlet. These connect into the large plastic handnut (black or green). This tank will also connect to earlier models of Metal Fusion cooker regulators which had a brass plug connector with left hand threads, which will connect to the internal threads of the Type 1 tank valve (with a wrench). If your tank has a quick disconnect valve (plug in type) our regulators can not connect to this tank.

**4. I have a brand new cooker and I cannot get the burner to light. What's the problem?**

Answer: Make sure the tank has been filled with propane. Tanks purchased from the store shelf are most often sold empty. If this does not solve the problem refer to Maintenance Instruction items #3 and #4, page 17. If you have questions please call Metal Fusion, Inc. at (800) 783-3885.

**IF YOU HAVE A QUESTION WE HAVE NOT ADDRESSED IN THIS MANUAL  
PLEASE SEND US AN E-MAIL AT [info@kingkooker.com](mailto:info@kingkooker.com) OR CALL 1-800-783-3885  
BETWEEN 7:30 A.M. AND 3:30 P.M. CST MONDAY THROUGH FRIDAY.**



# NOTES

# Outdoor Cooker Safety Precautions

## **WARNING!**

FAILURE TO FOLLOW THESE INSTRUCTIONS AND WARNINGS COULD RESULT IN FIRE, EXPLOSION, BURN HAZARD OR CARBON MONOXIDE POISONING WHICH COULD CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

Read and understand the entire Assembly Instructions and Use and Care Manual before using this product. If you lose your manual and need a replacement, or have questions, please contact us at 1-800-783-3885 between the hours of 7:30 A.M. and 3:30 P.M. CST Monday - Friday.

*WARNING: This Product Contains, and Its Use Will Create Chemicals Known to The State of California to Cause Cancer and Birth Defects (Or Other Reproductive Harm).*



**USE ONLY OUTDOORS!**



**DO NOT** use under any overhang or roof. Keep a minimum clearance of 10 ft. (3.05m) on all sides of the cooker.



**DO NOT** use on combustible surfaces.



**ALWAYS** keep children, pets and any unauthorized persons away from cooker.



**ALWAYS** wear protective mitts and use extreme caution not to splash hot oil.



**NEVER LEAVE COOKER UNATTENDED** while in use or still hot.



**ALWAYS** wear shoes while cooking. Keep hair and clothing from coming into contact with the cooker while in use or still hot.



**ALWAYS** turn the burner **OFF** when cooking is complete.



**ALWAYS** thaw and dry food completely before cooking.

KING GRILLERDINE, KING KOOKER®, the KING KOOKER® logo, THE KING, THE KING OF OUTDOOR COOKING, MR. OUTDOORS, and WATCHDOG OUTDOOR COOKER SERIES are trademarks of Metal Fusion, Inc., 712 St. George Avenue, Jefferson, LA 70121